

SIDE-A:

1. What's in the box

2. Get to know your camera

3. Specifications

Maximum resolution: 1520x1080
Lens: 110° wide-angle
Audio: Built-in mic/speaker, full duplex
Alerts: Smart AI based notifications
Enhancement: 3D noise reduction
Sensor: Temperature/Humidity
Wi-Fi: 2.4 GHz, 802.11ac/b/g/n
Night Light: Support
Platforms: Android / iOS
Wireless Security: WEP/WPA/WPA2
Power Supply: DC 5V/2A (MicroUSB)
Pan/Tilt: Manually 300°/100°

4. Getting started

Please make sure your camera is near your Wi-Fi router and your phone is on the same Wi-Fi network.

Download the Kami Home App from the Apple App Store or Google Play. Search for "Kami Home".

Step 1 Download the Kami Home App from the Apple App Store or Google Play. Search for "Kami Home".

Step 2 Plug in your camera to switch it on. If you are installing a camera that has previously been installed on a different network or you've changed your Wi-Fi password, then you must first reset the camera by pressing the reset button. Continue to follow the instructions.

Step 3 Sign up or login to your Kami account, then follow the on-screen instructions to pair your phone to your Kami camera.

Step 4 After logging in to your Kami Home App, click the + sign to select your device or scan the QR product code. When you hear the voice prompt "waiting to connect", tap "heard voice prompt". Next, scan the QR code on the App with your camera. Wait until you hear the voice prompt "pairing successful".

Now your camera is ready to use!

5. Wall mounting diagram

The Kami Wall Mount needs to be installed at the center of the wall behind and above your baby's crib. This gives you the best view possible of your baby, and ensures the camera to track your baby.

SIDE-B:

6. Notes for safe use

Strangulation Hazard: Children have STRANGLED in cords. NEVER attempt to use this cord without its protective covering. Check protective covering before each use to ensure that the cord is not exposed to your child. Immediately discontinue use if protective covering is damaged or broken. Adult assembly required.

CHOKING HAZARD: This product contains small parts which may cause choking. Keep small parts away from children.

ELECTRIC SHOCK WARNING: Never use this device near water, including near a bathtub, sink, laundry tub, wet basement, etc.

Ensure your child standing with arms outstretched cannot reach the camera.

Never use extension cords with AC adapter. Only use the AC adapter provided.

This product is not intended for use as a medical camera and its use should not replace adult supervision.

This device is designed for indoor use only.

This product and accompanied accessories are not toys. Do not allow children to play with them.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC WARNING

This device contains (source exempt transmitter(s) location(s) that comply with Innovation, Science and Economic Development Canada's license exempt RSS. Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

The distance between user and products should be no less than 20cm.

ADVERTENCIA IC

Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSSE) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- Cet appareil ne doit pas causer d'interférences.
- Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

La distance entre l'utilisateur et de produits ne devrait pas être inférieure à 20cm.

印刷公差 ≤ 0.5mm
SCALE 1:1

- 切刀
- 压线
- 齿刀
- 开槽
- 半穿
- 粘合

项目号 ▶ Y501C	项目名称 ▶ Kami Baby Monitor	印刷颜色 ▶ PANTONE 541 C PANTONE Cool Gray 11 C+黑	物料材质 ▶ 105g双胶纸	图号 ▶ 501C
设计于 ▶ 王伟	物料名称 ▶ 说明书(英文版)	成品尺寸 ▶ 122 × 207mm	特种工艺 ▶ 风琴折	料号 ▶ 6099

审核人员
设计主管 ▶
产品经理 ▶
质量工程 ▶
认证工程 ▶
软件测试 ▶
部门总监 ▶
通知人员
项目经理 ▶
采购经理 ▶

SIDE-A:

1. What's in the box

- User Manual
- Kami Camera + 360 Speaker
- Power Adapter
- Bunny Costume
- Micro USB cable 3m
- Screw x2
- Cable Cover x8
- Wall Mount

2. Get to know your camera

- ① Microphone
- ② Lens
- ③ Indicator Light
- ④ On / Off Night Light
- ⑤ On / Off Speaker
- ⑥ SD Card Cover
- ⑦ Hinge
- ⑧ USB Power Port
- ⑨ SD Card Slot
- ⑩ RESET

3. Specifications

Maximum resolution: 1520x1080
Lens: 110° wide-angle
Audio: Built-in mic/speaker, full duplex
Alerts: Smart AI based notifications
Enhancement: 3D noise reduction
Sensor: Temperature/Humidity
Wi-Fi: 2.4 GHz, 802.11ac/b/g/n
Night Light: Support
Platform: Android / iOS
Wireless Security: WEP/WPA/WPA2
Power Supply: DC 5V/2A (MicroUSB)
Pan/Tilt: Manually 300°/100°

4. Getting started

Please make sure your camera is near your Wi-Fi router and your phone is on the same Wi-Fi network.

Download the Kami Home App from the Apple App Store or Google Play. Search for "Kami Home".

Step 1 Download the Kami Home App from the Apple App Store or Google Play. Search for "Kami Home".

Step 2 Plug in your camera to switch it on. If you are installing a camera that has previously been installed on a different network or you've changed your Wi-Fi password, then you must first reset the camera by pressing the reset button. Continue to follow the instructions.

Step 3 Sign up or login to your Kami account, then follow the on-screen instructions to pair your phone to your Kami camera.

Step 4 After logging in to your Kami Home App, click the + sign to select your device or scan the QR product code. When you hear the voice prompt "waiting to connect", tap "heard voice prompt". Next, scan the QR code on the App with your camera. Wait until you hear the voice prompt "pairing successful".

Now your camera is ready to use!

5. Wall mounting diagram

The Kami Wall Mount needs to be installed at the center of the wall behind and above your baby's crib. This gives you the best view possible of your baby, and ensures the camera to track your baby.

Please make sure your camera is near your Wi-Fi router and your phone is on the same Wi-Fi network.

H=110-120cm (Recommended distance between camera and mattress top surface)

Distance = a

SIDE-B:

The mounting wall should support at least 30times the total weight of the bracket and the camera.

1 Find a suitable location, draw a screw hole to fix it, and follow the picture to install the wall mount. Use the screws to install the wall mount on a flat wall.

2 Connect the micro USB cable.

3 Rotate clockwise to mount.

4 Rotate counter clockwise to unmount.

5 Plug micro USB cable into the slot.

6 Check that cable cover looks straight vertically and press firmly on to the bottom of the cover.

1 Install the wall mount cover.

2 Press the down first until it clicks.

3 Press here.

4 Remove the protective cover.

5 Peel off 2 tape backings at the back of the cable cover.

6 Cover this part.

7 Press the top first until it clicks.

8 Install the cable cover.

9 Pay attention to the direction, this end is down.

10 Keep adding. Pay attention to the pressure line.

1 Adjust angle of the camera.

Horizontal Rot: left: 60° right: 240°

Vertical Rot: Up 50° Down 50°

6-8 Cable Covers

1 Connect the power supply.

6. Notes for safe use

Strangulation Hazard: Children have STRANGLED in cords. NEVER attempt to use this cord without its protective covering. Check protective covering before each use to ensure that the cord is not exposed to your child. Immediately discontinue use if protective covering is damaged or broken. Adult assembly required.

CHOKING HAZARD: This product contains small parts which may cause choking. Keep small parts away from children.

ELECTRIC SHOCK WARNING: Never use this device near water, including near a bathtub, sink, laundry tub, wet basement, etc.

Ensure your child standing with arms outstretched cannot reach the camera.

Never use extension cords with AC adapter. Only use the AC adapter provided.

This product is not intended for use as a medical camera and its use should not replace adult supervision.

This device is designed for indoor use only.

This product and accompanied accessories are not toys. Do not allow children to play with them.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC WARNING

This device contains licence-exempt transmitter(s) (receiver(s)) that comply with technical specifications for licence-exempt transmitter(s) (receiver(s)) that comply with Part 247 of the Radio Regulations. Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

The distance between user and products should be no less than 20cm.

ADVERTENCIA IC

Cet appareil contient des émetteur(s) / récepteur(s) exempts de licence conformes aux RSS (RSSE) d'innovation, Science et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- Cet appareil ne doit pas causer d'interférences.
- Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

La distance entre l'utilisateur et de produits ne devrait pas être inférieure à 20cm.

CE, IC, FCC

FCC ID: J4898 V95019
IC: 24548 V95019

- 切刀
- 压线
- 齿刀
- 开槽
- 半穿
- 粘合

印刷公差 ≤ 0.5mm
SCALE 1:1

审核人员

- 设计主管 ▶
- 产品经理 ▶
- 质量工程 ▶
- 认证工程 ▶
- 软件测试 ▶
- 部门总监 ▶

通知人员

- 项目经理 ▶
- 采购经理 ▶

项目号 ▶ Y501C

项目名称 ▶ Kami Baby Monitor

印刷颜色 ▶ PANTONE 541 C 专色: M35 Y45
PANTONE Cool Gray 11 C+黑

物料材质 ▶ 105g双胶纸

图号 ▶ 501C

设计于 ▶ 王伟

物料名称 ▶ 说明书(英文版)

成品尺寸 ▶ 122 × 207mm

特种工艺 ▶ 风琴折

料号 ▶ 6099